



# **RINGCONE<sup>®</sup>**

## **Adjustable Speed Drive**

**200B to 18K**

**NRX**  
Series

**Instruction Manual**

### Contents

Safety Precautions	1
Operating Precautions	2
Storing Precautions	4
Installation	5
Operation	6
Special Lubricating Oil	8
Periodical Inspection	11
Troubleshooting	11
Disassembly & Reassembly	12

# Safety Precautions

Be sure to read before use.



Thank you for purchasing the NIDEC DRIVE TECHNOLOGY product. To use this product properly and safely, please be sure to read this manual thoroughly before use. Keep this instruction manual where all users can read and/or refer to it at any time.

Before use, please carefully read these safety precautions and follow them for proper use.

This instruction manual categorizes safety precautions as DANGER, WARNING, and CAUTION according to level of importance. Each precaution has an important explanation related to safety. Be sure to observe all precautions.



**DANGER**

Indicates a potentially hazardous situation that may result in fire, serious injuries, and/or death if you incorrectly handle this product by neglecting the following precautions.



**WARNING**

Indicates a potentially hazardous situation that may result in serious injury if you incorrectly handle this product.



**CAUTION**

Indicates a potentially hazardous situation that may result in minor or moderate injury and/or property damage if you incorrectly handle this product. However, more severe results may also occur depending on the situation if mishandled. Be sure to observe all precautions.

The type of precautions we would like you to observe is categorized using the following symbols, and explanations are added (some examples as given below).



A reminder to pay close attention.



A prohibited action you must not do.



A forced action you must always do.

- We are not responsible for damages resulting from negligence through failure to follow the instructions set out in this manual.
- We are not responsible for damages resulting from earthquake and/or fire unrelated to us, actions by third parties, or any other accidents, intentional or through customer negligence, as well as from accidents caused by misuse or improper use under abnormal conditions.
- For information regarding assurance provisions, please read the attached warranty certificate.

## Precautions for installation

<p><b>Do not connect this product to a power source beyond the specified voltage range.</b> If you connect the product to a power source beyond the voltage range indicated on the motor nameplate, the heated motor could result in motor burns and fire.</p>	<p><b>Be careful of electric shock during connection.</b> Do not connect the product with wet (or sweaty) hands. Before wiring, be sure to turn the power OFF. Failure to follow this could result in electric shock.</p>
<p><b>Do not touch the keyway on the input and output shafts with bare hands.</b> Be careful to touch the keyway. Failure to follow this could result in injury on your hands or fingers due to the sharp edges.</p>	<p><b>Do not install Ringcone in a place directly exposed to rain or water.</b> Failure to follow this could result in electric shock, fire, and/or malfunction. When you use or install the product outdoors, select an outdoor model.</p>
<p><b>Install the product on a rigid surface that is not prone to vibration.</b> If the installation surface is not rigid enough, the machine could fall over during operation or a device could be damaged due to excessive vibration.</p>	<p><b>Mount a safety cover on the rotational items.</b> Failure to follow this could result in injury on your hands or fingers if you come into contact with the rotational items.</p>
<p><b>Do not install the product in an area with an ambient temperature of lower than 0°C and higher than 40°C.</b></p>	<p><b>If you use the product in a transportation device, or lifting device, apply protective device like brake for safety.</b></p>
<p><b>Disconnect the power supply for motor, when connecting.</b></p>	<p><b>To prepare pan or something for an oil leakage, if the leaking makes serious issues on application such as food, chemical machines, etc.</b></p>
<p><b>Heavy! Be careful when carrying.</b> Failure to follow this could result in serious injury if you drop the product on your feet accidentally during carrying or installation.</p>	

## Precautions for operation

<p><b>Do not use the product in an atmosphere with a risk of fire and/or explosion.</b> If you use this product in an atmosphere with risk of fire and/or explosion, select the explosion-proof model.</p>	<p><b>Do not touch the unit because it may become hot during operation.</b> Failure to follow this could result in burns.</p>
<p><b>Do not touch the rotating parts during operation.</b> Do not touch the output shaft, input shaft, or fan.</p>	<p><b>Avoid operation overloaded.</b> If you operate the unit with overload, the heated motor could result in motor burns and/or fire.</p>
<p><b>Before rotating the motor reversely, be sure to stop it completely.</b></p>	

## Precautions for inspection and maintenance

<p><b>Turn the power OFF during inspection.</b> Confirm the power source complete off before inspection &amp; maintenance.</p>	<p><b>Do not touch the unit during operation and immediately after operation stops.</b> The housing temperature will not decrease immediately after operation stops. Confirm that the temperature of the product has decreased before touching for inspection and/or disassembly.</p>
--	---

# Operating Precautions

## About this product


### ■ Input Speed

- Allowable input speed: NRX-200B to 7500 ... 700rpm to 2000rpm based on the standard specifications.  
NRX-11K to 18K ... 900rpm to 1800rpm

When using the product with a lower input speed than the above, please contact us.

### ■ Output Speed

- When using product continuously, use it in the middle and high-speed areas, which secures high efficiency.
- If a special request was not given at the time of order, the rotation speed is set to 0 rpm when a light load is applied.
- If you continuously use this unit in the low-speed area of 100 rpm(\*1) or less, it could be susceptible to load changes, and the rotation speed might become unstable.




Middle- and high-speed areas...  
Indicates the range between 3 and MAX on the dial.

### ■ Dial Plate & Load

- The output speed will not change as long as a load does not change.  
If a load changes greatly, however, the output speed might change even at the same dial plate position.
- Note that the output speed might change if a load changes greatly.  
\*We recommend using the automatic control when high accuracy is desired.

(\*1) Output speed without the reducer



### ■ Lubricating oil

Lubricating oil plays an important role, which can be used not only for power transmission, but also for burn, wear, rust prevention, and for cooling.  
Since lubricating oil greatly influences the performance of the product and service life, be sure to use the special lubricating oil only.

- Be sure to use the specified lubricating oil.
- Do not mix any other lubrication.
- If you use this product in an area with an ambient temperature of 0°C or less, or 40°C or more, heat- or cold-resistant lubricating oil is required.
- Since, unless otherwise requested, the speed drive is filled with the proper amount of lubricating oil before shipping, additional lubrication is not required.
- Check the oil level every day.
- Keep the replacement interval, and replace accordingly.

\*Refer to "[3] Special lubricating oil" described on page 8.

For purchase of the lubricating oil (special traction drive oil for the speed change section), contact us or any of the ENEOS Corporation offices.

## Precautions during operation

- At initial operation, confirm the rotating direction of the output shaft, and gradually apply the load.
- The handle rotational direction and increasing or decreasing speed may depend on the handle mounting direction. For more information, please contact us.
- The surface temperature of the speed drive housing under normal operation can reach up to approximately 50°C higher than the ambient temperature.
- Switch between forward and reverse rotation after the motor (input) shaft stops completely.
- Never change the speed when operation stops.
- Be careful not to overload.
- NRX is an output torque limiting model. Especially in the middle- and high-speed areas, the speed drive may be overloaded even with the motor rated current value or less. For more information, please contact us.

## Inspection

◎ If abnormal high temperature, noise, vibration, and/or oil leakage occur, stop operation immediately and contact us.

### ■ Daily inspection

- Check to ensure that the load condition is appropriate.
- Check to ensure that the speed drive housing temperature is not extremely high during operation (A temperature of up to approximately 50°C higher than the ambient temperature will not cause any problems).
- Check to ensure that there is no abnormal rolling noise with the bearings and/or traction drive parts.
- Check to ensure that abnormal vibration is not being generated from the speed drive.

#### <Lubricating oil inspection>

- Check to ensure that the lubricating oil is supplied to the appropriate indication level (check when operation stops).
- Check to ensure that the lubricating oil is not dirty, and that the degree of transparency is high.
- Check to ensure that there is no oil leakage  
(for example, check oil seals on the input and output shaft parts, O-rings, oil gauge, and the area around the oil filling and drain ports).

### ■ Periodical inspection (every three months)

- Check to ensure that pulleys, sprockets, and speed drive mounting bolts are not loose.
- Check to ensure that there are no problems in the electrical system.
- Check to ensure that the load condition is appropriate.
- Replacement of lubricating oil  
\*Refer to “3-1 Special lubricating oil list” and “3-2 Replacement of lubricating oil” , and use the special lubricating oil.

# Storing Precautions

If you do not plan to use the product immediately after purchase, store it under the following precautions.

## To store temporarily

- (1) Store the product in a clean and dry place.
- (2) If you store the product outdoors or in a humid place, put it in a box, seal the box, and cover with plastic sheets.
- (3) When storing, attach a red rubber stopper into the air release plug, or set a plug stopper to prevent humidity from entering the product.

## To store for a long period of time

- 1) When storing the product in outdoor areas subject to a lot of rain and/or humidity after installing on the site
  - (1) Cover the whole product with a water-proof sheet, and fix the sheet securely to prevent it from coming off due to strong wind, as well as to avoid entering rain and/or dust from clearance gap.
  - (2) If moisture is expected to evaporate from the ground, put the water-proof sheet underneath to prevent exposure to humidity from the evaporation, filling inside the sheet.
  - (3) When storing, attach a red rubber plug into the air release plug, or set a plug stopper to prevent humidity from entering the product.
  - (4) Set the cover on the motor terminal box, and seal the lead wire openings to avoid humidity from entering through the terminal box to the inside of the motor.
- 2) When storing the product indoors
 

When there is less humidity, cover the product with a plastic bag, etc., and follow the procedures described in (3) and (4) above.
- 3) When storing the product for a long period of time, over a year, special rust-proofing specifications are required in addition to the above procedures.
- 4) Rust-proofing intervals and procedures

Rust-proofing interval		Within one year (our shipping standard)		Over one year to less than three years (our recommendation)		
Instructions at ordering		No particular instructions are necessary		"Special rust-proofing specifications" need to be instructed		
Rust-proofing area		Rust-proofing procedures at factory shipping	Rust-proofing oil agent	Rust-proofing procedures at factory shipping	Rust-proofing oil agent	Procedures after shipping
Exposed parts of the product, input/output shafts, and flange section		Input/output shafts After rinsing, wrap plastic tape around.  Flange section After rinsing, apply the rust-proofing oil agent to it, and pack the whole part with a plastic bag.	JIS K2246 NP-2  Idemitsu Daphne Evercoat PL, or equivalent	Input/output shafts After rinsing, apply the rust-proofing oil agent to them, and wrap plastic tape around.  Flange section After rinsing, apply the rust-proofing oil agent to it, and pack the whole part with a plastic bag.	Equivalent to JIS K2246 NP-19  Taiyu Sabiden SAP D-15K, or equivalent	Check the condition of the rust-proofing one year after shipping, and re-apply the rust-proofing oil, if necessary. After that, carry out the same procedure every year.
Inside of the product	Grease	Special grease supplied at shipping	—	Special grease supplied at shipping	—	No special procedures are necessary
	Oil	Special oil supplied at shipping (The air breather has been sealed)	—	Add special oil thoroughly inside the housing. (The air breather has been sealed)	—	Take the same procedures as in the left, two years after shipping. When starting operation, replace with new oil, and fill to the specified level.
Supplied oil cooler pump unit	Water-cooled system	Operate with special oil, and drain oil at shipping. (The air breather has been sealed) Eliminate water from pipes completely, dry, and seal the cooling water openings.	—	Add special oil thoroughly inside the unit. (The air breather has been sealed) Eliminate water from pipes completely, dry, and seal the cooling water openings.	—	Take the same procedures as in the left, two years after shipping. When starting operation, replace with new oil.
	Air-cooled system	Operate with special oil, and drain oil at shipping. (The air breather has been sealed)	—	Add special oil thoroughly inside the unit. (The air breather has been sealed)	—	Take the same procedures as in the left, two years after shipping. When starting operation, replace with new oil.

[Note]: Only when the export rust-proofing specifications or instructions are given, rust-proofing oil is applied to the input/output shafts even in less than one year.

## Inspection during storage

Perform periodical inspection to check that the aforementioned storage procedures have been taken properly, and that the storing methods are correct.

## Inspection before resuming operation


- (1) Return the product to normal conditions from those taken for storage (such as for the amount of special oil).
- (2) Since bearings may partially run out of grease resulting from the grease hardening during long-term storage, be sure to turn the motor shaft by hand from the fan side before operation, and check that there are no problems.
- (3) Since exposed parts of rubber and/or resin parts in the oil seal, O-ring, and oil gauge, etc., may become deteriorated due to environmental influences, such as temperature, humidity, and/or ultraviolet rays, check those parts before resuming operation. If any deterioration is found, replace with new ones.

# 1 Installation


## 1-1 Installation

1. Avoid installing the product in a place directly exposed to rain or water.
  - Consult us in advance if you use the product outdoors, or in a place exposed to dust or water.
2. Install the product in an area with an ambient temperature of between 0°C and 40°C.
  - If you plan to use the product beyond the above mentioned temperature range (at higher or lower temperature), be sure to consult us.
3. Securely fix the product using bolts on a solid installation bench that is not prone to vibration.
  - Install the horizontal type horizontally, the vertical type (with downward output shaft) and inverted type (with upward output shaft) vertically. Failure to follow this could result in malfunction due to poor lubrication.  
For inclined installation, consult us.
4. Install the product in a way that provides easy access for inspection and maintenance.
  - To make it easy to add and drain lubricating oil, install the product at a level of approximately 10 cm from the floor by securing a top clearance of approximately 30 cm.
  - When installed the product into machines, place it so that the oil level can be checked externally, and lubricating oil can be easily replaced using pipes.

### [ Output shaft direction and installation direction ]



### [ Installation conditions ]



## 1-2 Connections

1. Allow a sufficient margin when setting the rotating speed and torque.
  - When driving the mated machine at the maximum speed, connect the speed drive so that it also operates at the maximum rotation.
  - For machines of which torque increases at the lower speed (such as those with constant horsepower characteristics), set the maximum torque to be within the rated torque of the speed drive.
2. When connecting the product, do not apply impact force and/or excessive thrust load on the output shaft (use tapping hole on the output shaft for 11K to 18K).

Ⓐ Since the output shaft diameter dimension tolerance of the speed drive has been set to h6 for 200B to 7500, and m6 for 11K to 18K, set the hole tolerance of the coupling, pulley, chain sprocket, and gear, which are to be mounted, to H7 for 200B to 7500, and F7 for 11K to 18K. Then, push the output shaft into the hole by tapping with a wooden or plastic hammer. Pushing the shaft by hitting it hard could result in damage to bearings and/or the inside of the speed drive.

Ⓑ Chamfer the hole mouth by approximately 1 mm.



Ⓒ Make clearance of 0.1 mm to 0.2 mm for the key head.

Ⓓ Hold and secure the key head using a set bolt.

**[Note]:** Make the effective diameter of the coupling, pulley, chain sprocket, and gear, etc. at least five times the output (input) shaft diameter of the speed drive. Be careful not to allow impact, vibration, and/or excessive thrust load from the machine to apply to the shaft ends. (For information about allowable shaft weight, refer to the catalog).

3. Ensure centering before connection.

- For connection with a coupling, properly align the speed drive shaft with the mated machine shaft.
- For connection with pulley, chain sprocket, and gear, etc., properly make the speed drive shaft parallel with the mated machine shaft, determine the correct center line, and fit precisely.



**[Note]:** The output shaft rotation direction for the speed drive equipped with a Coronet speed reducer (N11, 17, 29, 35, 47, 59, 71 types) is the same as that of the input shaft.

## 1-3 Connection with the oil cooler pump unit

For NRXMK-18K (including models equipped with the reducer)


Since the forced cooling system has been adopted, be sure to connect the supplied oil cooler pump unit according to the following procedures.

- Install the oil cooler pump unit at the same level as the oil gauge level of the speed drive.
- Be sure to provide a separate power supply from the speed drive motor.

### 1 Connection method


- Since the speed drive has been shipped with the proper amount of special lubricating oil supplied inside, **do not open the oil inlet (outlet) valves of the speed drive** until all hoses have been connected completely.
- 1. Be sure to connect the main unit and oil cooler pump unit using the supplied rubber hoses (two pieces).
- 2. Connect “IN” of the connection manifold in the unit to the connecting port on the side of the oil outlet in the speed drive, and “OUT” to the connecting port on the side of the oil inlet in the speed drive.

#### [Water-cooled system]



- Connect the cooling water hose (needed to be prepared by your company) to the cooling water flow conduit. Pass the cooling water with a flow rate of 20 liter/min.

#### [Air-cooled system]




## 2 Operation

### 2-1 Precautions before starting operation

1. Since, unless otherwise requested, the speed drive is filled with the proper amount of lubricating oil before shipping, additional lubrication is not required \*  
(Before use, check that lubricating oil has been supplied at the specified level of the oil gauge just in case).

\* Note that models with the rod-shaped oil gauge have not been filled with lubricating oil.

- Before use, be sure to remove the (red) pressure-release rubber plug attached to the breather cap at the oil filling port. Also, for models equipped with the reducer (G, W, N types), be sure to remove the (red) pressure-release rubber plug attached to the oil port cap of the reducer.



2. Check that electrical wiring has been performed properly.
3. Check that connection to the mated machine has been performed properly (fitting conditions, centering, etc.).
4. At initial operation, confirm the rotating direction of the output shaft, and gradually apply the load.

## 2-2 Precautions during operation

1. Never turn the speed change handle when operation stops (when the motor is not running).
2. Be careful not to overload.
3. The surface temperature of the speed drive housing under normal operation can reach up to approximately 50°C higher than the ambient temperature.
4. If the following events occur, stop operation immediately, and inspect the unit. Take any necessary procedures.

Symptoms	Possible causes
<ul style="list-style-type: none"> <li>• The temperature suddenly increases.</li> <li>• An abnormal, loud noise is suddenly generated.</li> <li>• The rotation speed suddenly becomes unstable.</li> <li>• Other abnormal events are found.</li> </ul>	<ul style="list-style-type: none"> <li>• The unit has been overloaded</li> <li>• Lubricating oil has been excessively or insufficiently used, or has deteriorated. Or, a different type of lubricating oil has been used.</li> <li>• Bearings and/or drive surfaces have been damaged</li> <li>• Improper connecting conditions with the mated machine, etc.</li> </ul>

\* For more details on the above symptoms and possible causes of problems, refer to "[5] Troubleshooting" on page 11.


5. Switch between forward and reverse rotation after checking that the motor (input) shaft has stopped operation completely. Instantaneous switching between forward and reverse rotation could result in malfunction.

## 2-3 Dial graduation and load

For NRX, the rotation will not change as long as the load does not change.

If a load changes greatly, however, the rotation speed will change even at the same graduation point.

1. Read the graduation on the dial depending on the load.
2. Note that the rotation speed will change if a load changes greatly.  
(We recommend using the automatic control when high accuracy is desired).




(\*1) Rotation speed for the type without the reducer

## 2-4 Operation of the oil cooler pump unit

For NRXMK-18K (including models equipped with the reducer)

- Operate the oil cooler pump unit according to the following procedures.
  - Be sure to provide a separate power supply to the pump unit from the speed drive motor.
- 1 Before operation, be sure to open the oil inlet (outlet) valves (two positions) of the speed drive.  
\* Operating the pump unit with those valves closed could result in malfunction of the pump unit.
  - 2 Turn the power switch of the oil cooler pump unit ON, and confirm that there is no problem with oil feeding conditions between the speed drive main unit and pump unit, then turn the power switch of the speed drive ON.



Open the oil inlet (outlet) valves of the speed drive



Turn the power switch of the oil cooler pump unit ON



Confirm that the oil cooler pump unit has been filled with oil



Turn the power switch of the speed drive ON

Confirm that oil has been supplied at the specified level of the oil gauge in the speed drive

- 3 Confirm the rotation direction of the cooler pump unit motor.
  1. Perform wiring so that the motor rotates in a counter-clockwise direction when viewed from the motor fan side.
  2. For the indication position of the rotation direction, refer to the table on the right.

Model	Indication position
RXCA-01 RXCW-01	Indicated on the motor
RXCW-01-1 RXCW-01-2	Indicated on the pump unit

- 4 Inspection and cleaning of the oil filter

• The filter clogging condition will be indicated by "color" in the detector inside the filter on top of the oil cooler pump unit, depending on the degree of use.

Blue → Normal    Yellow → Clean the element    White → Danger (clean or replace the element)



- When the detector indication ring turns **yellow**, remove the cover on top of the filter, and clean the element using light oil, etc.


#### Precautions for the water-cooled pump unit

- Check that water is always running in the oil cooler pump unit.
- If there is a risk of water freezing due to being in cold regions, a time of extreme cold, or when interrupting operation, remove the drain plug of the pump unit, and drain the water from it.
- Since accumulated water deposit inside the pump unit could result in a decrease in cooling function, clean the cooling water conduit once a year.

**Note:** When cleaning the water conduit, remove the water chamber covers on both sides.

#### Precautions for the air-cooled pump unit

- When removing the radiator, drain oil first, and remove the outlet/inlet pipes, four supporting bolts (6 x 15), two pan head screws on the fan side (4 x 50), fan, and then motor, in this order. If a large amount of oily dust is attached to the radiator, soak in a warm water solution with dissolved neutral detergent, and rinse in water. After that, blow compressed air on it.
- Clean oil deposit using solvent (Trichloroethylene) approximately once a year (Deteriorated oil will be dissolved gradually in the solvent. Leave solvent inside for approximately 30 minutes).



## 3 Installation

### 3-1 Special Lubricating Oil

Lubricating oil plays an important role in power transmission, and also has various effects on burn, wear, and/or rust prevention, and/or cooling.

Since lubricating oil greatly influences the performance of the product and product life, be sure to use the special traction drive oil for the speed change section. The type of lubricating oil differs between the speed change and speed reduction sections. In the event that different types of oil are used, sufficient performance may not be attained, or extension of the product life may be greatly influenced.

- The type of lubricating oil differs between the speed change and speed reduction sections. In the event that different types of oil are used, sufficient performance may not be attained, or extension of the product life may be greatly influenced.

Speed drive				Reducer type	Planetary/Pinion reducer			Inscribed planetary reducer				Worm reducer				
Speed drive model		RX-60 to 3700 NRX-60 to 7500 ARX-60 to 750 SC-200E to 22000C O-200E to 1500E	RX-5500 7500 NRX-11K 15K	RX-11K to 15K NRX-18K to 30K		Speed drive model	RX-60 / 90 NRX-60 / 90 ARX-60 / 90	RX-200B NRX-200B / 400B	RX-400 to 7500 NRX-750 to 18K ARX-400 to 750 SC-200E to 22000C O-200E to 1500E	RX-90 NRX-90 ARX-90	RX-200B to 15K NRX-200B to 30K ARX-400 to 750		RX-90 to 3700 NRX-90 to 5500 ARX-90 to 750 SC-200E to 3700E O-200E to 1500E			
		SC-200E to 3700E O-200E to 1500E														
Lubrication system	Speed change section			Gear section	Nominal reduction ratio	G3M / G5M	G3M / G5M	G3 / G5 / G6	G11 to G71	N(G)11 to 71 C11 to 87			W10 to W30			
	Oil lubrication			Forced oil lubrication	Oil lubrication	Reducer frame number	-	-	-	A / B	A / B / C	D to G	H to N	-		
Lubrication system		Grease			Grease	Oil	Oil	Grease	Oil			Oil				
Type	Special traction drive oil for the speed change section				JIS K 2219 Industrial Gear Oil Class 2 ISO VG220	Type(Viscosity)	NLGI No.1 Grease	NLGI No.0 Grease	JIS K 2219 Industrial Gear Oil Class 2 ISO VG220	JIS K 2213 Turbine Oil Class 2 ISO VG46	NLGI No.2 Grease	JIS K 2219 Industrial Gear Oil Class 2 ISO VG100	JIS K 2219 Industrial Gear Oil Class 2 ISO VG320			
Brand	Idemitsu		RINGCONE Traction Drive Oil TD Oil 10		RINGCONE Traction Drive Oil TD Oil 22	Daphne Super Gear Oil 220	Brand	Idemitsu		Daphne Polylex No.0	Daphne Super Gear Oil 220	Daphne Mechanic Oil 46	-	Daphne Super Gear Oil 100	Daphne Super Gear Oil 320	
	ENEOS					Bonnoc TS220		ENEOS		Epnoc Grease AP1	Pyronoc Grease No.0	Bonnoc TS220	FBK Oil RO46	-	Bonnoc TS100	Bonnoc TS320
	Mobil					Mobilgear 600XP 220		Mobil		Mobilux EP No.1	-	Mobilgear 600XP 220	DTE Oil Medium	-	Mobilgear 600XP 100	Mobilgear 600XP 320
	Showa Shell					Omala S2G 220		Showa Shell		Alvania EP No.1	Stamina RL No.0	Omala S2G 220	Tellus S2M 46	-	Omala S2G 100	Omala S2G 320
	Cosmo					Cosmo Gear SE 220		Cosmo		Dynamax EP No.1	-	Cosmo Gear SE 220	Cosmo Allpus 46	-	Cosmo Gear SE 100	Cosmo Gear SE 320
										Kyodo Yushi	Unilube DL No.1	Excellite EP No.0	-	-	-	-
Replacement interval	Every 20,000 hours, or every 4 ~ 5 years		Every 5,000 hours, or every year		Replacement interval	Nippeco		-	-	-	NDS Grease	-	-			
					Replacement interval		Every 20,000 hours, or every 4 ~ 5 years		Every 5,000 hours, or every year		Every 20,000 hours, or every 4 ~ 5 years	Every 5,000 hours, or every year				

**Note** 1. For lubricating oil supplied at shipping, contact us accordingly.

2. The oil replacement interval differs depending on conditions of use. In particular atmospheres subject to high humidity and/or active gas, shorten the replacement interval described in the above table.

- When using the product at especially low temperatures (approximately -30°C to 0°C) or high temperatures (approximately 40°C or more), heat or cold-resistant lubricating oil and applicable internal parts are required. For details, consult us in advance.
- For purchase of special traction drive oil, contact us or any of the ENEOS Corporation offices.

### 3-2 Replacement of lubricating oil

#### Speed change section

For special traction drive oil, the oil lifespan is extremely long, and the replacement interval is very long.

\* For the replacement interval, refer to the above table.

#### Speed reduction section

Replace lubricating oil described in the above table at the specified replacement interval.

### 3-3 Oil filling and draining


- Never mix different types of oil. Failure to follow this could result in adverse effect due to the change in oil quality.
- Oil leakage could result in accidents. Wipe away oil spills at the time of filling or draining.

[ For the speed change section ]

- Add oil up to the specified level of the oil gauge when the speed drive stops.

[Note] : Continuing operation with insufficient oil could result in damage to internal parts.

Check the oil level every day.




[Note] : For the vertical type, be sure to set the unit vertically before adding oil. If oil is added with the unit placed horizontally, the amount of oil will differ, and proper lubrication management cannot be performed. If oil has been added excessively, remove the drain plug, and drain out surplus oil to adjust the amount.

[Note] : Before adding oil in the vertical type of models 200B to 1500, be sure to remove the attached pressure relief plug for lubrication, which can be used to release the internal air pressure. After adding oil, attach the pressure relief plug.

[For the speed reduction section]

- The plug position in the center of the speed reduction section indicates the proper oil level. Remove the upper lubrication plug and level plug, and fill with oil until oil flows out of the level plug.




- For the grease lubricated system <Frame A/B/C of N(G)11 to 71>, additional refill is not required in the middle of the replacement interval. When replacing oil, disassemble the unit for overhaul before lubrication.

### 3-4 Proper amount of oil, and oil filling/draining plug positions


NRX □ (L)

Model	Horizontal type	Vertical type
	Speed change section	Speed change section
200B	0.2	0.4
400B	0.2	0.4
750	0.5	1.0
1500	0.8	1.9
2200	1.8	2.7
3700	2.5	4.8
5500	2.8	5.4
7500	2.2	5.4
11K	5.0	15
15K	5.0	15
18K	5.0	15




NRX □ - □ -G □ Planetary/Pinion reducer (L)

Model	Reduction ratio	Horizontal type		Vertical type	
		Speed change section	Speed reduction section	Speed change section	Speed reduction section
200B	G3M/G5M	0.2	Grease	0.4	Grease
400B	G3M/G5M	0.2	Grease	0.4	Grease
750	G3/6	0.5	0.4	1.0	0.4
1500	G3/6	0.8	0.5	1.9	0.8
2200	G3/6	1.8	1.0	2.7	1.3
3700	G3/6	2.5	1.5	4.8	2.3
5500	G3/6	2.8	1.8	6.5	3.5
7500	G3/6	2.2	1.8	6.5	3.5
11K	G3/5	5.0	9.0	15	18.2
15K	G3/5	5.0	9.0	15	18.2
18K	G3/5	5.0	9.0	15	18.2





NRX □ - □ - W □ Worm reducer (L)

Model		Speed change section	Speed reduction section		
			H □ U	V □ D	V □ U
200B	W10/20/30	0.2	0.25	0.4	0.4
400B	W10	0.2	0.25	0.4	0.4
	W20/30	0.2	0.5	0.6	0.6
750	W10	0.5	0.5	0.6	0.6
	W20/30	0.5	0.7	0.85	0.85
1500	W10	0.8	0.7	0.85	0.85
	W20/30	0.8	1.3	1.5	1.5
2200	W10	1.8	1.3	1.5	1.5
	W20/30	1.8	2.1	2.7	2.7
3700	W10	2.5	2.1	2.7	2.7
	W20/30	2.5	3.3	4.1	4.1
5500	W10	2.8	3.3	4.1	4.1
	W20/30	2.8	5.5	7.5	7.5



NRX □ - □ -  $\frac{N}{C}$  □ Inscribed planetary reducer (L)

Model	Reduction ratio	Frame size	Horizontal type		Vertical type	
			Speed change section	Speed reduction section	Speed change section	Speed reduction section
200B	G11/17	A	0.2	Grease	0.4	Grease
	N29 to 71	B	0.2	Grease	0.4	Grease
400B	N11 to 71	B	0.2	Grease	0.4	Grease
750	N11 to 29	B	0.5	Grease	1.0	Grease
	N35 to 71	C	0.5	Grease	1.0	Grease
1500	N11 to 29	C	0.8	Grease	1.9	Grease
	N35 to 71	D	0.8	0.9	1.9	1.5
2200	N11 to 47	D	1.8	0.9	2.7	1.5
	N59 to 71	E	1.8	1.8	2.7	2.4
3700	N11 to 29	D	2.5	0.9	4.8	1.5
	N35 to 71	E	2.5	1.8	4.8	2.4
5500	N11 to 47	E	2.8	1.8	5.4	2.4
	N59/71	F	2.8	3.2	5.4	4.3
7500	N11 to 35	E	2.2	1.8	5.4	2.4
	N47 to 71	F	2.2	3.2	5.4	4.3
11K	C11 to 43	H	5.0	4.6	15	7
	C87	L	5.0	15	15	18
15K	C11 to 43	H	5.0	4.6	15	7
	C87	L	5.0	15	15	18
18K	C11/21	H	5.0	4.6	15	7
	C29/43	L	5.0	15	15	18



Model 11K, 15K, 18K

## 4

## Periodical Inspection


### 4-1 Daily inspection

- Check to ensure that the speed drive housing temperature is not extremely high during operation.  
\* A temperature of up to approximately 50°C higher than the ambient temperature will not cause any problems.
- Check to ensure that there are no abnormal rolling sounds with the bearings and/or friction transmission parts.
- Check to ensure that abnormal vibration is not being generated from the speed drive.  
\* If any of these abnormal events occur, stop operation immediately, disassemble and inspect the unit, or contact us.
- Confirm that oil has been supplied at the specified level of the oil gauge (Check when the unit stops).
- Check to ensure that the oil has not been contaminated. Check to ensure that oil gauge is transparent enough.
- Check to ensure that there is no oil leakage anywhere (for example, in oil seals on the input and output shaft parts, O-rings, oil gauge, and/or the area around the oil filling and drain ports, etc.).  
\* If any oil leakage occurs, replace the necessary parts, or contact us.

### 4-2 Periodical inspection (approximately at least every three months)

- Check to ensure that there is no excessive overload.
- Check to ensure that pulleys, sprockets, and speed drive mounting bolts are not loose.
- Check to ensure that there are no problems in the electrical system.
- Inspect and maintain major parts.  
\* If abnormal sounds occur inside of the speed drive, stop operation immediately, disassemble and inspect the unit, or contact us.
- Check to ensure that the specified time of replacement for lubricating oil has not passed.  
\* Check to ensure that oil level has not decreased, and that it's not dark in color. Check the specified replacement interval.

## 5 Troubleshooting



## 6 Disassembly & Reassembly

If problems or malfunction have occurred in the unit, and disassembly inspection is required, refer to the disassembly and reassembly figures on the following pages, and perform accordingly (refer to “5 Troubleshooting” on page 11).

**Note:** Since models larger than the medium-scale type (1.5 kW type), and those equipped with the reducer have heavy parts, hoist or crane equipment may be required at the time of disassembly and reassembly.

**Note:** When disassembly and reassembly are performed by our workers, please have your company remove and mount the speed drive.

### 6-1 Disassembly procedure

- (1) Remove the plug from the oil drain port, and drain oil completely.
- (2) Remove the top cover.
- (3) Remove the output shaft assembly from the main unit.
- (4) Remove the cam assembly from the output shaft assembly.
- (5) Remove the cone assembly.
- (6) Remove the ring assembly.
- (7) Remove the input disc from the motor shaft.

#### • Inspection & Washing

- After disassembly, inspect each part, and wash all parts with washing oil.
- Replace defective parts with normal ones.

Keep all disassembled parts away from dust until reassembly.

### 6-2 Reassembly procedure

- Perform reassembly in the reverse order of disassembly.
- Put packing in joint parts between the M flange/output shaft holder/motor and the main unit housing/covers. In such cases, replace deformed or cracked packing with normal one.
- \* When reassembly is complete, adjust pressure contact force inside according to “6-3 Shim (pressure contact force) adjustment”.

### 6-3 Shim (pressure contact force) adjustment

- Since shim (pressure contact force) has been sufficiently adjusted at shipping, readjustment is not necessary before use.

When disassembly and reassembly have been performed due to unavoidable circumstances, readjust shim according to the following procedure.

**NRX** ☐ \*For models with the reducer, refer to the respective page.

#### ● Adjustment procedure

When reassembly is complete after disassembly, in order for the “automatic pressure adjustment mechanism” to function effectively, adjust pressure contact force using the shim inside the bearing cover.

- When reassembling the speed change section, move the ring to the low speed end (output shaft) in advance.



#### ● Procedure

- (1) Tighten the bearing cover completely.
- (2) Mount a pulley on the output shaft, and manually turn the pulley from side to side to seat internal parts.

NRX <input type="checkbox"/> -200B/400B NRX <input type="checkbox"/> -750 to 2200
Adjust by output shaft backlash

- (3) When turning the pulley from side to side, check that output shaft backlash is within the range of values in the table below.  
If backlash is too large or small, remove the bearing cover, and adjust to the normal value by increasing or decreasing the shim (0.1 mm to 0.2 mm thick).

Model	Output backlash
200B/400B 750/1500	1° to 3°
2200	After adjusting to 1° to 3°, add a shim 0.2 mm thick.





- (4) When shim (pressure contact force) adjustment is complete, mount the top cover, and set the dial.  
Under no load, align the mating mark with 0 (zero) for NO LOAD on the dial, and tighten using the bolt.

NRX <input type="checkbox"/> -3700 to 18K
Adjust by clearance between the cam disc and input cam

- (3) Remove the top cover.
- (4) Look into the inside of the main unit, and check that clearance between the cam disc and input cam is within the range of values in the table below.  
If clearance is too large or small, remove the bearing cover, and adjust to the normal value by increasing or decreasing the shim (0.1 mm to 0.2 mm thick).

Model	Clearance of the cam disc
3700 to 18K	Adjust clearance to 0 to 0.1 mm, and add a shim 0.1 mm to 0.15 mm thick (0.05 mm to 0.1 mm thick when applying pressure).



- (5) When shim (pressure contact force) adjustment is complete, mount the top cover, and set the dial.  
Under no load, align the mating mark with 0 (zero) for NO LOAD on the dial, and tighten using the bolt.

NRX □ - □ -G □ with planetary reducer

NRX □ - □ -W □ with worm reducer

- When reassembly of the speed change and reduction sections is complete after disassembly, adjust pressure contact force according to the following procedure.

- When reassembling the speed change section, move the ring to the low speed end (output shaft) in advance.


### ● Procedure

- (1) Remove the top cover in the speed change section, look into the inside, and adjust pressure contact force according to the following procedure.
- (2) Only for W type (with worm reducer), loosen the hexagon socket set screw. \*Refer to the disassembly and reassembly diagram for the worm reducer section on page 19

NRX □ -200B to 2200-G □
NRX □ -200B to 2200-W □
Adjust by cam retainer backlash

- (3) Hold the cam retainer with pliers, etc., and check that the total backlash is within the range of values in the table below.  
If backlash is too large or small, remove the bearing cover (HS blind cover for W type), and adjust to the normal value by increasing or decreasing the shim (0.1 mm to 0.2 mm thick).


Model	Cam retainer backlash
200B/400B 750/1500	1° to 3°
2200	After adjusting to 1° to 3°, add a shim 0.2 mm thick.



NRX □ -3700 or larger -G □
NRX □ -3700 or larger -W □
NRX □ -11K to 18K-C □ H/L
Adjust by clearance between the cam disc and input cam

- (3) Look into the inside of the speed drive, and check that clearance between the cam disc and input cam is within the range of values in the table below.  
If clearance is too large or small, remove the bearing cover (HS blind cover for W type), and adjust to the normal value by increasing or decreasing the shim (0.1 mm to 0.2 mm thick).

Model	Clearance of the cam disc
3700 to 18K	Adjust clearance to 0 to 0.1 mm, and add a shim 0.1 mm to 0.15 mm thick (0.05 mm to 0.1 mm thick when applying pressure).



- (4) Only for W type (with worm reducer), tighten the hexagon socket set screw after shim (pressure contact force) adjustment.
- (5) Set the dial.



\* Refer to the procedure for the standard NRX □ on page 12.

- When reassembly of the speed change and reduction sections is complete after disassembly, adjust pressure contact force according to the following procedure.

- When reassembling the speed change section, move the ring to the low speed end (output shaft) in advance.

### ● Procedure

- (1) Put a rod (T-wrench) etc. into the ER flange adjustment hole, and align the ER flange and adjuster surfaces on the same level by turning the adjuster. After that, assemble the main units of the speed reduction and change sections.



- (2) Remove the top cover in the speed change section, look into the inside, and adjust pressure contact force by turning the adjuster with a rod (T-wrench) etc. according to the following procedure.


- (3) Check pressure contact force adjustment according to the tables below.

(Turning the adjuster clockwise increases contact force, and turning counterclockwise decreases contact force when viewed from the output shaft)

NRX □ -200B to 2200-N □
Adjust by cam retainer backlash

- (4) Hold the cam retainer with pliers, etc., and check that the total backlash is within the range of values in the table below. If backlash is too large or small, turn the ER flange adjuster, and make adjustment.


Model	Cam retainer backlash
200B/400B 750/1500	1° to 3°
2200	After adjusting to 1° to 3°, turn the adjuster by one pitch to increase contact force



NRX □ - 3700 to 7500-N □
Adjust by clearance between the cam disc and input cam


- (4) Look into the inside of the speed drive, and check that clearance between the cam disc and input cam is within the range of values in the table below. If clearance is too large or small, turn the ER flange adjuster, and make adjustment.

Model	Clearance of the cam disc
3700 to 7500	After adjusting clearance to 0 to 0.1 mm, turn the adjuster by one pitch to increase contact force



- (5) When shim (pressure contact force) adjustment is complete, secure the adjuster using the fixing bolt, and set the blind bolt on the other side.

**[Note]:** The fixing bolt is used to keep the adjuster from turning. Keep the tip of the bolt from coming into contact with the bottom of the adjuster.



- (6) Set the dial.

\*Refer to the procedure for the standard NRX □ on page 12.



# Disassembly and reassembly diagram for speed change section 1 NRXM (K) –200B to 7500

\* For the speed reduction section, refer to the disassembly and reassembly diagram for the respective speed reduction section on pages 18 to 21.

## Bearing name number list

Bearing position	Output shaft A	Output shaft B	Output shaft C	Input disc D	Input disc G	Motor shaft E	Motor shaft F
Model	6203ZZ	6203	—	51204	—	—	—
200B/400B	6203ZZ	6203	—	51204	—	—	—
750	6204ZZ	TMB204	51204	51305	—	—	—
1500	6206ZZ	6206	51206	51405	—	—	—
2200	6207ZZ	6207	51207	51407	—	—	—
3700	6208ZZ	6307	51307	51408	—	—	—
5500/7500	6210ZZ	6308	51308	51410	6011	6210LLU	6011LLU

A, B, E, F, G: Ball bearing (ZZ: metal seal type, LLU: contact rubber seal type) C, D: Thrust bearing

Vertical type of NRXM(K)-200B/400B

\*The bearing type on the output shaft A is LLU.


When the sensor gear is attached, the bearing type on the output shaft B is also LLU.

Inverted type of NRXM(K)-750 or larger

\*The bearing type on the output shaft A and B is LLU.

## Oil seal name number list

Seal position	Output shaft R	Input shaft S
Model	D17328	—
200B/400B	D17328	—
750	D20358	—
1500	D30458	—
2200	D35508	—
3700	D40588	—
5500/7500	D507212	S507212





## 2


\* For the speed change section, refer to page 15.

## NRXK

Bearing name	Bearing position		Input shaft F	Input shaft E	Input shaft F	Input shaft G
	Modell	Modell				
2008/400B	51204	6005ZZ	6005ZZ	6005ZZ	6005ZZ	—
750	51305	6007ZZ	6007ZZ	6007ZZ	6007ZZ	—
1500	51405	6008ZZ	6008ZZ	6008ZZ	6008ZZ	—
2200	51407	6209ZZ	6209ZZ	6209ZZ	6209ZZ	6008
3700	51408	6209ZZ	6209ZZ	6209ZZ	6209ZZ	6010
5500/7500	51410	6210LLU	6210LLU	6211LLU	6211LLU	6011

## Oil seal name number list

Model	Seal position	Motor shaft S
200B/400B		S20358
750		S25408
1500		S25408
2200		S35508
3700		S40558
5500/7500		S507212



# Disassembly and reassembly diagram for speed change section

## 3 NRXMK-11K to 18K

\*For details on the speed reduction section, please refer to the disassembly and reassembly diagram for the respective speed reduction section on pages 19 and 22.


Bearing name number list

Bearing position	Output shaft A	Output shaft B	Output shaft C	Input disc D	Input disc H	Motor shaft E	Motor shaft F
Model	11K, 15K	6312ZZ	6312ZZZ	88315	6013	6213LLU	6212LLU
	18K	6312LLU for the inverted type	6312LLU for the inverted type			6213LLU	6213LLU

A, C, E, F, G, H: Ball bearing (ZZ: metal seal type, LLU: contact rubber seal type)  
B, D: Thrust bearing

Oil seal name number list

Seal position	Output shaft R	Motor (Input) shaft S
Model	11K to 18K	D608212
		S659013



—

750 to 7500 G3 / G6

**Bearing name number list**

Model	Beeping position	Output shaft 2A	Output shaft 2B	Output shaft 2C	G3		G6	Input shaft 2G
					Planetary gear 2D	Planetary gear 2E		
750	6206L LU	6007	4T-30203	HK 1212(2)	IR 8 × 12 × 16.5(2)	6200(3)	6203Z2	
1500	6207L LU	6009	4T-30204	HK 1516(2)	IR 12 × 13 × 16.5(2)	6202(3)	6205Z2	
2200	4T-30208	6010	4T-30205	6001(4)	-	6203(3)	6206Z2	
3700	4T-30210	6012	4T-30206	6002(4)	-	6204(3)	6207Z2	
5500/7500	4T-30211	6013	4T-30207	6002(4)	-	830(3)	6208Z2	

6012 × 12.5(2)	6200(3)	6205ZZ
12 × 15 × 16.5(2)	6202(3)	6205ZZ
-	6203(3)	6206ZZ

5500/7500	4T-30211
-----------	----------


	-
	-
	=
	.
	-
	-
	=
	(
	*
	2

2A: Ball bearing or taper roller bearing (LLU: contact rubber seal type) 2B, 2F, 2G: Ball bearing (ZZ: metal seal type)  
2C: Taper roller bearing 2D: Needle bearing or ball bearing 2E: Shaft washer

Oil seal name number list

Seal position		Output shaft 2R	Input shaft 2S
Model			
750		D30458	S 25408 (2)
1500		D35508	S 32458 (2)
2200		D40588	S 38558 (2)
3700		D50729	S 42659 (2)
5500/7500		D5729	S 50729 (2)

The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.



## Disassembly and reassembly diagram for planetary and pinion reducer section

2

### NRXMK-11K to 18K-G3,G5

\*For the speed change section, refer to page 17.

#### Bearing name number list


Bearing position		Output shaft	Pinion shaft	Pinion shaft
Speed drive model	Reduction ratio	2A	2B	2D
11K to 18K	G3/G5	HR32216J	HR32213J	HR32207J

The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.

#### Oil seal name number list

Seal position		Output shaft	Output shaft
Speed drive model	Reduction ratio	R	2R
11K to 18K	G3 / G5	D608212(2)	D8010513

2A, 2B, 2C, 2D: Tapered roller bearing



#### Parts list

- 1 Cone retainer
- 2 Cone
- 13 Speed drive output shaft
- 17 Cam disc (on the output shaft side)
- 34 Bearing cover
- 35 O-ring
- 36 Shim
- 38 Packing
- 39 Coupler
- 251 Housing
- 253 Cover on the low speed side
- 254 Bearing housing on the low speed side
- 255 Primary pinion
- 256 Primary gear
- 257 Secondary pinion
- 258 Secondary gear
- 259 Output shaft
- 260 Key for the primary pinion
- 261 Key for the primary gear
- 262 Key for the secondary gear
- 263 Spacer for the secondary pinion shaft
- 264 Drain plug
- 265 Oil gauge
- 266 Vent hole
- 267 Eye bolt
- 268 Pin for the cover on the low speed side
- 269 Locknut for the primary pinion
- 270 Stud bolt for the high speed ring
- 272 Bolt for the cover on the low speed side
- 273 Bolt for the bearing housing on the low speed side
- 276 Packing for the cover on the low speed side
- 277 Secondary pinion
- 278 Shim for the shaft bearing
- 278 Shim for the low speed shaft bearing
- 2A to 2D : Bearing
- R, 2R : Oil seal

Each part has been assembled in the speed reduction section.  
For replacement, the reducer assembly needs to be replaced.

## Disassembly and reassembly diagram for worm reducer section

### NRXM(K)-200B to 5500-W10/W20/W30

\*For the speed change section, refer to page 15.

#### Bearing name number list


Bearing position		Output shaft	Worm shaft	Worm shaft
Model	W10 / W20 / W30	4A	4B	4C
200B	W10 / W20 / W30	6204LLU(2)	7203 BDF(2)	6905
400B	W10 / W20 / W30	6205LLU(2)	7204 BDF(2)	6005
750	W10 / W20 / W30	6206LLU(2)	7304 BDF(2)	6204
1500	W10 / W20 / W30	6207LLU(2)	7305 BDF(2)	6007
2200	W10 / W20 / W30	6208LLU(2)	7306 BDF(2)	6910
3700	W10 / W20 / W30	6210LLU(2)	7308 BDF(2)	6210
5500	W10 / W20 / W30	6212LLU(2)	7309BDF(2)	6211

The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.

#### Oil seal name number list

Seal position		Output shaft	Worm shaft
Model	W10 / W20 / W30	4R	4S
200B	W10 / W20 / W30	S 20358	S 25357 (2)
400B	W10 / W20 / W30	S 25408	S 25357 (2)
750	W10 / W20 / W30	S 305011	S 28408 (2)
1500	W10 / W20 / W30	S 355511	S 35508 (2)
2200	W10 / W20 / W30	S 406212	S 50659 (2)
3700	W10 / W20 / W30	S 507212	S 50729 (2)
5500	W10 / W20 / W30	S 608212	S 557812(2)

4A, 4C: Ball bearing (LLU: contact rubber seal type)  
4B: Angular bearing



For details on the speed change section, refer to page 15



# Disassembly and reassembly diagram for CORONET reducer section

1 N11 to N71 Frame A, B, C / NRXM (K) –200B to 1500–G□A, N□C

\*For the speed change section, refer to page 15.

Bearing name number list

Bearing position		Output shaft 3A	Output shaft 3B	Input shaft 3C	Input shaft 3G
Frame size	Reduction ratio				
A	G11	6206 ZZ	6008 ZZ	NF 153212	JR 121512
	G17				
B	N11	6307 ZZ	6209 ZZ	NF 153212	JR 121512
	N17,29,35,47,59,71				
C	N11	6309 ZZ	6212 ZZ	NF 2204	JR 172016
	N17,29,35,47,59,71				

3A, 3B, 3E: Ball bearing (ZZ: metal seal type)

3C: Roller bearing, 3F: Thrust bearing, 3G: Shaft washer

NRXMKY-200B/400B

\*The bearing type on the input shaft 3E for the inverted type is LLU when the sensor gear is attached.

Oil seal name number list

Seal position		Output shaft 3R	Input shaft 3S
Frame size	Reduction ratio		
A	G11,17	D30458	S 26388 (2)
	D30458		
B	N11,17,29,35,47,59,71	D45629	S 30458 (2)
	D45629		
C	N11,17,29,35,47,59,71	D55709	S 35508 (2)
	D55709		


The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.

## Parts list

- 1 Cone retainer
- 2 Cone
- 15 Output cam
- 16 Cam retainer
- 17 Cam disc
- 38 Packing (on the output shaft side)
- 301 Base
- 306 Output shaft
- 307 Output shaft bush
- 309 Distance collar
- 310 Bush
- 311 Wheel
- 312 Wheel spacer
- 313 Eccentric roller bearing
- 317 Carrier pin
- 319 Internal pin
- 320 Internal pin housing
- 321 ER flange
- 334 Cover
- 335 O-ring
- 336 Adjuster
- 337 Counter Shaft bush
- 338 Input shaft
- 339 Snap Ring Shaft
- 340 Thrust seat
- 341 Balance weight
- 370 Packing (on the output shaft side)
- 371 Packing (on the input shaft side)
- 381 Vertical flange
- 383 Stud bolt
- 3A to 3G: Bearing
- 3R, 3S; Oil seal

Bearing name number list

Bearing position		Input shaft 3E	Input shaft 3F
Speed drive model			
200B	6304ZZ	6304ZZ	–
	400B		
750	6304ZZ	6305 ZZ	51204
	1500		



## Example of disassembly procedure


- 1 Remove the base (remove the output shaft assembly).
- 2 Remove the wheel, bush, and eccentric roller bearing on the output shaft side.
- 3 Remove the spacer.
- 4 Remove the wheel, bush, and eccentric roller bearing on the input shaft side.
- 5 Remove the ER flange from the speed change section.

## Perform reassembly in the reverse order of disassembly


Note 1: Put packing in joint parts on both sides of the internal housing, and in those of the speed change section. Replace deformed or cracked packing with normal one.

Note 2: Frame symbols and numbers have been stamped on two wheels. When assembling,

turn the stamped mark on two wheels upward, and move the stamped mark on one wheel by 180° from the other.



Note 3: Move the bush reversely from the eccentric direction. (refer to the figure below)




Note 4: When assembling, turn the stamped mark downward for one eccentric roller bearing, and move eccentricity by 180° for the balance weight.



Frames B and C

Turn the stamped mark upward for one eccentric roller bearing and turn it downward for the other bearing, which enables eccentricity to be moved by 180°. Apply grease to the rotation part of the roller before assembling.



Note 5: Supply the specified amount of grease inside the reducer.

# Disassembly and reassembly diagram for CORONET reducer section

2

N11 to N71 Frame D, E, F / NRXM (K) -1500 to 7500-N□D, N□E, N□F

\* For the speed change section, refer to page 15.

## Bearing name number list

Frame size	Reduction ratio	Output shaft 3A	Input shaft 3C	Input shaft 3D	Input shaft 3E	Input shaft 3F
D	N11	6213NR	NF 2204	6010	6306 ZZ	51206
	N17,29,35,47,59,71		NF 2305	6210	6307 ZZ	51207
E	N11	6315NR	NF 2305	6015	6307 ZZ	51307
	N17,29,35,47,59,71		NF 2306		6309 ZZ	51308
F	N11,17	6319NR	NF 2306			
	N29,35,47,59,71		NF 2308	6216		

3A, 3D, 3E: Ball bearing (ZZ: metal seal type, NR: with snap ring)

3C: Roller bearing 3F: Thrust bearing

3A, LLU for the inverted type

3D, ZZ for the vertical type


## Oil seal name number list

Frame size	Reduction ratio	Output shaft 3R	Input shaft 3S
D	N11,17,29,35,47,59,71	D 751001	S 35508 (2)
E	N11,17,29,35,47,59,71	D 8511013	S 50659 (2)
F	N11,17,29,35,47,59,71	D11014014	S 50659 (2)
			S 55729 (2)

## Example of disassembly procedure

The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.

- 1 Remove the hexagon socket plug, and drain oil.
- 2 Remove the bearing cover.
- 3 Remove the snap ring of bearing 3A.
- 4 Remove the base.
- 5 Remove the bolt from the carrier pin, and release the output shaft.
- 6 Remove the wheel, bush, and eccentric roller bearing on the output shaft side.
- 7 Remove the spacer.
- 8 Remove the wheel, bush, and eccentric roller bearing on the input shaft side.
- 9 Remove the holder, and remove the ER flange from the speed change section.




## Parts list

- |                                       |   |
|---------------------------------------|---|
| 1 Cone retainer                       | 319 Internal pin                            |
| 2 Cone                                | 320 Internal pin housing                    |
| 15 Output cam                         | 321 ER flange                               |
| 16 Cam retainer                       | 322 Plug                                    |
| 17 Cam disc                           | 334 Cover                                   |
| 38 Packing (on the output shaft side) | 335 O-ring                                  |
| 301 Base                              | 336 Adjuster                                |
| 302 Bearing cover                     | 337 Counter shaft bush                      |
| 303 Snap ring                         | 338 Input shaft                             |
| 304 Spring pin                        | 339 Snap Ring Shaft                         |
| 305 Hexagon socket plug               | 340 Thrust seat                             |
| 306 Output shaft                      | 345 Spacer                                  |
| 307 Output shaft bush                 | 370 Output shaft (on the output shaft side) |
| 308 Positioning spacer                | 371 Packing (on the input shaft side)       |
| 309 Distance collar                   | 372 Packing (bearing cover part)            |
| 310 Bush                              | 381 Vertical flange                         |
| 311 Wheel                             | 382 Spring pin                              |
| 312 Wheel spacer                      | 383 Stud bolt                               |
| 313 Eccentric roller bearing          | 3A to 3F: Bearing                           |
| 317 Carrier pin                       | 3R, 3S: Oil seal                            |
| 318 Holder                            |   |

Note 3: Move the bush reversely from the eccentric direction. (refer to the figure below)



Note 4: Turn the stamped mark upward for one eccentric roller bearing, and turn it downward for the other bearing, which enables eccentricity to be moved by 180°. Apply grease to the rotation part of the roller before assembling.




Note 5: Supply the specified amount of oil inside the reducer.

## Perform reassembly in the reverse order of disassembly

Note 1: Put packing in joint parts on both sides of the internal housing, and in those of the speed change section. Replace deformed or cracked packing with normal one.

Note 2: Frame symbols and numbers have been stamped on two wheels. When assembling, turn the stamped mark on one wheel upward, and move the stamped mark on one wheel by 180° from the other.



Flange type

Base type

# Disassembly and reassembly diagram for inscribed planetary reducer section

3

C11 to C87 Frame H, L NRXMK-11K to 18K-C□H, C□L

\* For the speed change section, refer to page 17.

## Bearing name number list

Bearing position	Flange section		Speed reduction section	
	⑭	⑮	②	⑧
Frame size and reduction ratio				
H C11.21.29.43.87	6312	6312Z2	81212	6408
L C11.21.29.43.87	6312	5312	NJ313EV3	6026

The number of pieces is indicated in brackets. The number of pieces without bracket indication is one.

Oil seal name number list	
Seal position	Speed reduction section
Frame size and reduction ratio	
H C11.21.29.43.87	S8010513(2)
L C11.21.29.43.87	S8010513(2)

## Example of disassembly procedure

- Place the speed reduction section down, remove upper bolts, and separate the low speed section.

## Disassembly procedure for the speed reduction section


- Inner roller ⑦ Wheel is ⑮ Spacer ring ⑮ Snap Ring Shaft ①
- Bearing ② Distance piece B ③ End bracket ④ Eccentric Roller Bearing ④ (with bearing ⑤) Curve disc ④ End bracket ④ Size ④ Outer pin ④ Outer roller ④

## Disassembly procedure for the low speed section

- Cover (Gland) ① Snap ring shaft for bearing ⑦ Low speed shaft ⑥ (with ⑦ ⑧ ⑨ ⑩)


## Perform reassembly in the reverse order of disassembly

Note 1 : Frame symbols and numbers have been stamped on two wheels. When assembling, turn the stamped mark on two wheels up, and move the stamped mark on one wheel by 180° from the other.




Stamped mark

Note 2: Place both stamped surfaces outward, respectively, and assemble into the Eccentric Roller Bearing ④.



Note 3: Worn or damaged oil seals, collars, and/or packing, etc. could result in oil leakage. Be sure to replace them with new ones.



## Parts list

### Speed change section

- 1 Cone retainer
- 2 Cone
- 3 Ring
- 4 Rubber packing
- 5 Guide shaft
- 15 Output cam
- 16 Cam retainer
- 17 Cam disc
- 18 Input cam
- 19 Auxiliary spring
- 20 Spring
- 21 Needle roller
- 22 Spring seat
- 24 Rack gear holder
- 25 Rack gear
- 26 Cover packing
- 27 Cover
- 29 Dial Plate
- 30 Breather cap
- 38 Packing (on the output shaft side)
- 71 Input disc
- 74 Input shaft holder
- 76 Fan
- 77 Motor shaft


### Flange section

- ① Flange
- ③ Bearing cover
- ④ Collar
- ⑧ Counter Shaft
- ⑩ End bracket
- ⑭ Ball bearing
- ⑮ Ball bearing
- ⑯ Thrust roller bearing
- ⑰ Snap Ring Shaft
- ⑲ Plug
- ⑳ Shim

## Parts list

- ① Snap Ring Shaft
- ② Bearing
- ③ Distance piece B
- ④ End bracket
- ⑤ Bearing
- ⑥ Low speed shaft
- ⑦ Bearing
- ⑧ Bearing
- ⑩ Inner pin
- ⑪ Packing
- ⑫ Packing
- ⑬ Outer cover with flange
- ⑭ Oil seal
- ⑮ Gland
- ⑯ Collar
- ⑰ Plug
- ⑱ Upper bolt
- ⑲ Packing
- ⑳ Frame
- ㉑ Eccentric Roller Bearing
- ㉒ Wheels
- ㉓ Outer pin
- ㉔ Outer roller
- ㉕ Spacer ring
- ㉖ Inner roller


## Speed reduction section (vertical type)



## Parts list

- ① Snap Ring Shaft
- ② Bearing
- ③ Distance piece B
- ④ End bracket
- ⑤ Bearing
- ⑥ Low speed shaft
- ⑦ Bearing
- ⑧ Snap Ring Shaft
- ⑩ Inner pin
- ⑪ Packing
- ⑫ Packing
- ⑬ Outer side cover
- ⑭ Oil seal
- ⑮ Cover
- ⑯ Collar
- ⑰ Oil filling plug
- ⑱ Upper bolt
- ⑲ Packing
- ⑳ Frame
- ㉑ Eccentric Roller Bearing
- ㉒ Wheels

## Speed reduction section (horizontal type)













## NIDEC DRIVE TECHNOLOGY CORPORATION

〈Web Page Information〉 Please scan the QR code or access the URL below.



### Contact Us

<https://www.nidec.com/en/nidec-drivetechnology/inquiry/>



### Sales Offices

<https://www.nidec.com/en/nidec-drivetechnology/corporate/network/sales/>

Copyright NIDEC DRIVE TECHNOLOGY Corporation. All Rights Reserved.

## NIDEC DRIVE TECHNOLOGY CORPORATION

Nidec Shimpo Corporation change its company name to Nidec Drive Technology Corporation on April 1, 2023.